

8

7

6

5

4

3

2

1

NEXT ASS'Y

FINAL ASS'Y

GENERAL NOTES:

- FURNISH AND INSTALL UNDERGROUND DUCT BANKS AND EMPTY CONDUIT AS SHOWN ON THIS DRAWING AND DESCRIBED IN SPECIFICATIONS.
- FIELD VERIFY THE EXACT LOCATION OF ALL THE STUB-OUTS, DUCT BANKS AND CONDUIT ROUTINGS. COORDINATE WITH OTHER TRADES.

KEYNOTES:

- N001** FURNISH AND INSTALL: (4) - 2" PVC UNDERGROUND EMPTY SPARE CONDUITS WITH PULL WIRE AND EXTEND 5'-0" OUTSIDE OF BLDG. AND CAP. REFER TO BWSG DWG ULTS.35.01 AND .02 FOR CONTINUATION OF OUTDOOR LIGHTING REQUIREMENTS.
- N002** STUB CONDUITS UP 24" ABOVE GRADE.

